

IMPORTANT INFORMATION

SUBJECT:

Lubrication of DD capstan motor.

APPLICABLE TO:

MX-5050*, MX-70, MX-80, MTR-10/12, MTR-20, BTR-5 and BTR-10,
(*Except early MX-5050 which has belt drive capstan motor.)

LUBRICATION OIL:

ANDEROL 456-----OTARI Parts No. PZ9E003
No other oil should be used.

LUBRICATION PROCEDURE:

MX-5050, MX-70, MX-80, MTR-10/12 and BTR-10

---These motors have a foam-ring surrounding the top of the brass bearing.

1. Remove dust cap from the capstan motor.
2. Apply 1 or 2 drops of oil.

MTR-20 and BTR-5

---These motors have a felt-pad on top of the brass bearing.

1. Remove plastic dust cap from the motor.
2. Apply 1 or 2 drops of oil.

NOTICE:

1. Lubrication should be done after approximately 1,000 hours of operation or every 6 months depending on machine usage.
2. Don't over lubricate and don't apply oil to the part of the capstan shaft which has contact with the tape.
3. This oil will be included with each machine shipped after July 1st, 1987.